

	KİL FİTİLİ WEATHER STRIP SEALS ЩЕТОЧНЫЕ УПЛОТНИТЕЛИ		
ÜRÜN KODU CODE КОД	Ölçüler Dimensions Размеры	Metre/Rulo Meter/Roll Метер/Рулон	Metre/Koli Meter/boxes Метер/Коробка
RPT.001	48-300	800	800x4 = 3200
RPT.002	48-400	550	550x4 = 2200
RPT.003	48-450	550	550x4 = 2200
RPT.004	48-500	550	550x4 = 2200
RPT.005	48-550	500	500x4 = 2000
RPT.006	48-600	450	450x4 = 1800
RPT.007	48-650	450	450x4 = 1800
RPT.008	48-700	400	400x4 = 1600
RPT.009	48-800	325	325x4 = 1300
RPT.010	48-1000	250	250x4 = 1000
RPT.011	48-1200	200	200x4 = 800
RPT.012	51-400	500	500x4 = 2000
RPT.013	51-450	450	450x4 = 1800
RPT.014	51-500	425	425x4 = 1700
RPT.015	51-550	400	400x4 = 1600
RPT.016	51-600	350	350x4 = 1400
RPT.017	51-650	350	350x4 = 1400
RPT.018	51-700	325	325x4 = 1300
RPT.019	51-800	325	325x4 = 1300
RPT.020	51-1000	225	225x4 = 900
RPT.021	51-1200	200	200x4 = 800
RPT.022	55-500	425	425x4 = 1700
RPT.023	55-550	400	400x4 = 1600
RPT.024	55-600	375	375x4 = 1500
RPT.025	55-650	350	350x4 = 1400
RPT.026	55-700	350	350x4 = 1400
RPT.027	55-800	325	325x4 = 1300
RPT.028	60-575	350	350x4 = 1400
RPT.029	67-350	450	450x4 = 1800
RPT.030	67-400	400	400x4 = 1600
RPT.031	67-450	400	400x4 = 1600
RPT.032	67-500	375	375x4 = 1500
RPT.033	67-550	375	375x4 = 1500
RPT.034	67-600	350	350x4 = 1400
RPT.035	67-650	350	350x4 = 1400
RPT.036	67-700	300	300x4 = 1200

RPT.037	67-800	250	250x4 = 1000
RPT.038	67-900	225	225x4 = 900
RPT.039	67-1000	200	200x4 = 800
RPT.040	67-1100	200	200x4 = 800
RPT.041	67-1200	175	175x4 = 700
RPT.042	67-1500	125	125x4 = 500
RPT.043	67-1800	100	100x4 = 400
RPT.044	67-2000	100	100x4 = 400
RPT.045	69-500	375	375x4 = 1500
RPT.046	69-600	325	325x4 = 1300
RPT.047	69-700	250	250x4 = 1000
RPT.048	69-800	225	225x4 = 900
RPT.049	69-1000	200	200x4 = 800
RPT.050	69-1200	175	175x4 = 700
RPT.051	72-800	200	200x4 = 800
RPT.052	127-700	175	175x4 = 700
RPT.053	127-1000	150	150x4=600
RPT.1F	48-1000 F	500	500x2 = 1000
RPT.2F	51-550 F	700	700x2 = 1400
RPT.3F	51-650 F	650	650x2 = 1300
RPT.4F	51-800 F	600	600x2 = 1200
RPT.5F	51-1000 F	500	500x2 = 1000
RPT.6F	55-550 F	650	650x2 = 1300
RPT.7F	55-650 F	650	650x2 = 1300
RPT.8F	55-700 F	650	650x2 = 1300
RPT.9F	55-800 F	600	600x2 = 1200
RPT.10F	60-575 F	600	600x2 = 1200
RPT.11F	67-600 F	550	550x2=1100
RPT.12F	67-700 F	500	500x2 = 1000
RPT.13F	67-800 F	450	450x2 = 900
RPT.14F	67-1000 F	350	350x2 = 700
RPT.15F	67-1100 F	350	350x2 = 700
RPT.16F	67-1200 F	300	300x2 = 600
RPT.17F	69-500 F	550	550x2=1100
RPT.18F	69-600 F	550	550x2=1100
RPT.19F	69-700 F	450	450x2 = 900
RPT.20F	69-800 F	425	425x2 = 850
RPT.18F	69-1000 F	350	350x2 = 700
RPT.19F	69-1200 F	300	300x2 = 600
RPT.20F	72-800 F	350	350x2 = 700
RPT.18F	127-700 F	300	300x2 = 600
RPT.19F	127-1000 F	200	200x4 = 800